

Technical Manual

for

**Model No. LS-1A  
Linear Regulator**

With Over-Voltage Protection, Low-Voltage Sensing,  
And Field-Adjustable Charging Voltage

Including:

Installation Instructions;  
Troubleshooting Guide; and  
Instructions for Continued Airworthiness

**B & C Specialty Products  
P.O. Box B  
Newton, KS 67114  
(316) 283-8000**

## INTRODUCTION

This kit is applicable to any aircraft requiring external control and regulation of a B-type, wound-field Alternator.

## DESCRIPTION OF INSTALLATION

- (1) Remove engine cowl and disconnect aircraft battery.
- (2) Remove existing regulator (if applicable).
- (3) Install new Controller (Regulator).
- (4) Install 2A and 5A circuit breakers, alternator master switch, and incandescent warning light on instrument panel.
- (5) Wire the LS-1A Controller (Regulator), circuit breakers, alternator master switch, and incandescent warning light.
- (6) Reconnect battery and replace engine cowl.
- (7) Update ship's weight and balance, pilot operating handbook and maintenance records.

## PARTS LIST

The following parts are supplied with the LS-1A:

<u>Qty.</u>	<u>Part No.</u>	<u>Description</u>
1	LS-1A	Alternator Controller (Regulator)
8	S814R6	Terminal, Ring, 18-22AWG
1	S888-2-3	Warning Lamp, Incandescent, Yellow, 28v

The following parts are needed but **not** supplied with this kit:

<u>Qty.</u>	<u>Part No.</u>	<u>Description</u>
1	L-40, L-60, BC410-H (or equal)	Alternator
1	CB2 (or equal)	Circuit Breaker, 2A
1	CB5 (or equal)	Circuit Breaker, 5A
1	S700-2-3 (or equal)	Switch, Toggle
AR	M22759/16-18-9	Wire, 18 AWG, White, Tefzel
AR	M22759/16-22-9	Wire, 22 AWG, White, Tefzel
2	AN4-4A	Bolt
4	AN960-416L	Flat washer
2	AN365-428A	Locking nut

The above items are available, individually or as part of an installation kit (P/N: LR\_INSTALL), from B&C Specialty Products, [www.BandC.aero](http://www.BandC.aero), phone: 316-283-8000.

## CHANGE IN WEIGHT AND BALANCE

Installation of this kit will impact aircraft weight by a nominal 0.6 pounds. Variations in airframe station references for all aircraft affected by this kit prevent including pre-calculated weight and balance data in these instructions.

## INSTALLATION INSTRUCTIONS

### Preparation

- Step 1. Refer to applicable service manual instructions; remove and retain engine cowl. Disconnect ship's battery, Negative (-) terminal first.
- Step 2. Refer to applicable service manual instruction; remove existing regulator.
- Step 3. Select a suitable location to mount the LS-1A. Mounting on the pilot's side of the firewall, or inside the cabin near the panel, is preferred (linear controllers are electrically "quiet," and create no noise when properly installed).

#### NOTE

Take care to choose a mounting location that will protect the LS-1A from heat, vibration, and water.

- Step 4. Select a suitable location to mount the incandescent low voltage warning light (supplied) in your instrument panel. The light should be positioned within the pilots' peripheral vision — generally, a 45-degree angle in front of the pilot. A panel location away from direct sunlight is preferred.
- Step 5. Select a suitable panel location to mount the 2A and 5A circuit breakers. A panel location within the pilot's field of vision and reach is recommended.
- Step 6. Select a suitable panel location to mount the alternator field switch. A panel location immediately adjacent to the ship's battery master is recommended, if practicable.

### Regulator Installation

- Step 7. Mount the LS-1A to the firewall or selected location. On a metal firewall, AN4-4A bolts, AN960-416L flat washers, and AN365-428A locking nuts, will be adequate to secure the regulator.
- Step 8. Wire the LS-1A power and control circuits using M22759/16 Tefzel wire and the supplied S814R6 ring terminals, according to the wiring diagram on page 8.

#### NOTE

The LS-1A senses bus voltage through terminal #1. If the low voltage warning light is not desired, terminal #2 may be left unconnected; however terminal #1 **must still be connected** to the bus through a fuse or circuit breaker. If terminal #1 is not connected to power, the LS-1A **will not work**. Do not connect or "jumper" terminal #1 to terminal #6.

- Step 9. Wire the LS-1A to ground using M22759/16 Tefzel wire and the supplied S814R6 ring terminals, according to the wiring diagram on page 8. Be certain to establish ground connections to both terminal #7 and the threaded ground stud below the terminal strip.

**NOTE**

This step is important for all airframes, and *crucial* for composite aircraft. The LS-1A obtains a redundant connection to ground through the threaded stud. A jumper between terminal #7 and the ground stud will not provide this. Ground connections must be totally independent and not rely on common fasteners. Select 18AWG wire (or larger) and ring terminals for these connections.

- Step 10. Wire the 2A and 5A circuit breakers and alternator field switch using M22759/16 Tefzel wire, according to the wiring diagram on page 8.

**NOTE**

If panel space is limited, a 2A in-line fuse may be substituted for the 2A circuit breaker associated with terminal #2. The 5A circuit breaker associated with terminal #6 **MUST** be used. Connecting terminal #6 directly to the bus or using “solid-state breakers” (PTC thermistors) will damage the regulator if there is an over-voltage condition.

- Step 11. Wire the incandescent warning light using M22759/16 Tefzel wire, according to the wiring diagram on page 8. Place heatshrink (supplied) over each wire for the warning light base, solder the wires onto the base terminals, and shrink the heatshrink over the connection.
- Step 12. Connect ship’s battery, Negative (-) terminal last, and replace engine cowl.
- Step 13. Test the installation as follows —
- A. Low-voltage indication: turn the battery master switch ON, and observe the incandescent warning light. Depending on the condition of the battery, this light may or may not flash. If it does not begin flashing, turn on the landing light or the nav lights to lower the battery voltage sufficiently to make the warning light start to flash (typically between 25 and 26 volts).
  - B. System charging: start the engine according to normal procedure. With the engine running and the battery master switch ON, turn the alternator field switch ON. An increase in bus voltage to 28 to 28.8 volts should be observed, depending on the electrical load, engine RPM, and type of alternator (refer to the supporting documents for the alternator to determine the RPM at which measurable output may be expected). The low-voltage warning light should no longer flash.
- Step 14. Update ship’s weight and balance, pilot operating handbook and maintenance records.

## OPERATION OF THE LS-1A

The LS-1A is pre-set at 28.8v. If adjustment of alternator output voltage is needed, remove the 3/4" round plug from the side of the LS-1A and use a small screwdriver to turn the small adjustment screw (clockwise to increase voltage, counterclockwise to decrease voltage; approximately 1 turn equals .3 volts). Use a digital voltmeter at the battery for this measurement.

In normal operation the 5A field circuit breaker will be closed (ON) and the incandescent warning light will not be flashing. Depending upon battery type, condition and temperature, the warning light may flash a few times and then quit when the master switch is ON and the engine is not running.

LOW-VOLTAGE WARNING - continuous rapid flashing of the warning light.

OVER-VOLTAGE WARNING - the 5A alternator field circuit breaker will open causing alternator to be shut down. If sufficient loads are operational, the incandescent warning light will begin to flash in a few seconds. If electrical loads are very light, the warning light may take longer before flashing.

## INSTALLATION TIPS

1. Avoid deviating from the installation instructions and wiring diagram. The LS-1A has been designed to integrate into your aircraft electrical system in a very specific way, with separate bus connections for "sense" and "control". Similarly, the LS-1A also requires other associated components, such as circuit breakers and an alternator field switch, which meet certain specifications. These connections and associated components are vital to proper system function.
2. Use time-proven components in your installation. Our technical staff has found that a reliable installation is often made or broken by the associated parts used to install the LS-1A. Here are several specific choices that can help you avoid trouble:
  - Select a "toggle-type" rather than a "rocker-type" switch for the alternator field switch. Our tear-down analysis of the internals of each type has shown that the mechanical properties and basic materials used in a simple toggle switch will provide superior service over time. Avoid "split-rocker" switches in particular (a common source of reliability woes as they accumulate time in service).
  - Use KLIXON or Mechanical Products circuit breakers, frequently used in general aviation. These well-constructed, single-purpose devices are reasonably economical, and will serve you well over time. Avoid combination "switch-circuit breakers" (another common source of reliability issues).
  - Use nylon pre-insulated ring terminals (supplied), and crimp these with the correct tool. Route wiring along existing harnesses, where they exist, and secure with nylon wire ties. Insure that all wiring is tied away from chafe points and clear of all flight control mechanisms throughout the entire range of control movements. Use a 5-lb pull test to check crimped connections; verify the terminal is crimped on the wire, not the insulation.

- Avoid substituting an LED indicator light for the supplied incandescent warning light. The LS-1A is designed to drive an incandescent light only; an LED will not provide satisfactory results (viz. it will remain constantly illuminated, regardless of whether there is an actual over-voltage or low-voltage condition).
- Insure the integrity of your alternator field connector and associated wiring. The LS-1A connects to the alternator by means of a single wire; an intermittent connection at the alternator will result in erratic (and unstable) operation.

## TROUBLESHOOTING GUIDE

Refer to the wiring diagram found on page 8 and use a high impedance (preferably digital) volt/ohmmeter (DVM) to make the following checks. Please note that the engine should NOT be running, the mags should be OFF, and there should be no auxiliary power applied to the aircraft electrical system:

1. Turn all switches off. Use the lowest resistance scale on the DVM. Check resistance between the battery negative (-) terminal and both pin 7 of the regulator and the engine case. Measurements over 0.5 Ohm to either would be cause for investigation. In this case, check the engine ground strap, battery ground strap, and regulator ground wire for loose or contaminated connections, broken conductors or bad crimp joints. If these measurements are less than 0.5 Ohm, any of these three points may be used as reference (-) for the following measurements.

Resistance from battery to pin 7: \_\_\_\_\_ Ohms; from battery to engine case: \_\_\_\_\_ Ohms

2. Turn on the battery master and alternator field switches. Measure the voltage on the battery bus and on pin 1 of the regulator. The voltages should be equal within 0.2 volts. A difference of greater than 0.2 volts may be caused by using a breaker as the source for pin 1 that supplies another device of considerable load. Change to a lightly loaded breaker or a breaker dedicated to pin 1 and the low voltage lamp. It is recommended that pin 1 NOT be jumpered to pin 6. If pin 1 has no voltage, the regulator will not operate.

Bus voltage: \_\_\_\_\_ volts      Pin 1 voltage: \_\_\_\_\_ volts

3. Measure the voltage on pin 6 of the regulator. It should be within 0.5 volts of the bus voltage. A difference of greater than 0.5 volts may be caused by poor contacts in the field breaker or field switch, or poor crimp joints/loose screw terminals in the wiring between the bus and pin 6. Absence of voltage on pin 6 will prevent the regulator from operating.

Pin 6 voltage: \_\_\_\_\_ volts

4. Check the voltage on pin 5 of the regulator. The voltage should be between 13 and 15 volts. A voltage outside this range could indicate a bad regulator.

Pin 5 voltage: \_\_\_\_\_ volts

5. Move to the engine compartment. Without disconnecting the field connector, measure the field voltage on the alternator. Use a thin probe or small gage wire wrapped around the probe to reach through the connector body and measure the voltage on the male blade coming out of the alternator. It should measure within 0.5 volts of the measurement on pin 5 of the regulator. A lack of voltage may indicate an open circuit between pin 5 of the regulator and the field terminal. If an open field circuit is suspected, the switches may be turned off, the alternator field connector removed, and a resistance measurement made between the connector and pin 5 of the regulator. Look for near 0 Ohms. Typically the field resistance of the alternator will be between 3 and 10 Ohms from the male field terminal blade to alternator case.

Field terminal voltage: \_\_\_\_\_ volts      Alternator field resistance: \_\_\_\_\_ Ohms

6. With the switches on, check the voltage between the alternator output post (or “B”-lead) and ground. It should be battery voltage. If not, check the wiring between the alternator “B”-lead and the battery positive (+) terminal. Look for loose or contaminated connections, broken wires, or an open breaker or fuse.

Alternator “B”-lead voltage: \_\_\_\_\_ volts


7. If all of the voltages in the first 6 steps are close to the value specified, the charging system should be operative. If not, check for a broken or loose alternator belt. It is also possible on some installations that the engine speed will have to be near run-up RPM or more for the system to provide useable output.

Intermittent problems are the hardest to find. In composite aircraft a common root cause is poor system grounds; metal aircraft can exhibit this defect, also, if proper system grounding is not a priority.

Noise problems can also be challenging. To manage system noise problems, consider the following:


- A unitized grounding system helps prevent noise problems by preventing voltage differences between different ground points.
- The battery acts as a noise filter in the system. Poor connections to the battery, or a battery in the initial stages of failing, can add to or even cause noise problems.
- Shielding of low level audio leads (especially microphone leads or headset leads) is a necessity. Sometimes the shields in the cables can separate from repeated flexing; so a check of shield continuity with an ohmmeter may prove illuminating.
- Wire routing is important. Separate noise-carrying conductors (like “P”-leads) from other wiring. Avoid running noisy wiring parallel to other wiring in the same bundle.

# Wiring Diagram for LS1A Voltage Regulator



## EXPLANATION OF TERMINALS 1 THRU 7


1. Bus Sense
2. Warning Light (optional)
3. Temp Probe - white wire (optional)
4. Temp Probe - yellow wire (optional)
5. Field
6. Bus - Field Supply (to 5A circuit breaker)
7. Ground



**THIS PART IS NOT STC'd AND IS SOLD FOR AMATEUR BUILT AIRCRAFT ONLY.**

B&C SPECIALTY PRODUCTS 12/14





123 East 4th Street, P.O. Box "B", Newton KS 67114-0894  
Telephone (316) 283-8000 · Fax (316) 283-7400

---

**Instructions for Continued Airworthiness**  
**for**  
**B&C Specialty Products Model BC203-1 (LS1A) Alternator Controller**

The BC203-1 Alternator Controller has solid state circuitry and has no required replacement interval. Voltage adjustment of the BC203-1 is not normally required. Deviation from the factory set point of 28.8 volts by more than 0.2 volts may indicate the need for repair or replacement. If this set point is in question, it should be checked using a calibrated digital voltmeter sensing directly between terminals 1 and 7 of the regulator with the engine at over 2000 RPM and Bus load under 3 amps. A flashing low voltage warning light should occur at or below approximately 25.5 volts

The BC203-1 contains internal over-voltage protection. Grounding for both regulation and over-voltage protection is achieved through terminal 7 of the regulator, through the case mounting bolts and through the grounding stud provided under the terminal strip. At Annual inspections, check the security of the case mounting bolts and the wires attached to terminal 7 and the grounding stud. In addition, the over-voltage protection may be tested for correct operation in one of two ways:

1. Connection to terminal 6 may be isolated from the aircraft wiring at a convenient point and a current limited power supply with an output voltage adjustable between zero and 35 volts attached to terminals 6 and 7 with the positive lead on terminal 6. Connect a 10 ohm, 10 watt resistor from terminal 6 to terminal 5. Limit the output current to 5 amps or less and gradually raise the power supply voltage until the controller shorts the output of the power supply. The power should be removed from terminal 6 within 5 seconds of achieving the shorted condition. The short should occur between 32.0 and 33.0 volts. No short indicates the failure of the over-voltage protection circuitry of the controller and necessity for repair or replacement of the controller. If the test is satisfactory, switch power off, reconnect terminal 6 and remove the 10 ohm resistor.

2. Connection to terminal 6 may be isolated from the aircraft wiring at a convenient point and a 5 amp in-line fuse connected from the aircraft bus to the negative terminal of a 12 volt lantern battery. Connect

a 10 ohm, 10 watt resistor from terminal 6 to terminal 5. Energize the aircraft Bus and momentarily connect the positive terminal of the lantern battery to terminal 6 of the regulator. The fuse should blow immediately. If the fuse does not blow, the over-voltage protection circuit has failed and the regulator must be replaced or repaired. If the test is satisfactory, switch power off, reconnect terminal 6 and remove the 10 ohm resistor.

Failure due to broken wires or damaged connectors may be corrected using repair procedures complying with the latest revision of AC 43.13-xx. All other physical damage or incorrect operation should be referred to the manufacturer for evaluation and repair.

**IF THIS UNIT IS TO BE INSTALLED ON A TYPE-CERTIFICATED AIRCRAFT  
IT MUST BE ACCOMPANIED BY AN STC OR BY A ONE-TIME FIELD APPROVAL**