

Installation Instructions

- Connect positive battery cable to "B" terminal
- Connect starter motor cable to "M" terminal
- "I" terminal is not normally used. You can use this terminal to drive a "Starter Engaged" light on the panel.
- "S" terminal gets power to engage contactor from a "Start" push button or switch.

*Note – Contactor coil finds ground through the mounting base.